

MODERN BLACK PINS INSTRUCTIONS

Step 1:

Below is everything included with our Modern Black Pins.



Step 2:

Locate the backing board or wall space where you would like to install your black pins. Drill the appropriate number of holes then insert your pins into those holes.



Step 3:

On the otherside of the backing board/wall, insert the included hex socket head cap screws.



Step 4:

Using a screwdriver or similar tool, firmly turn the hex socket head cap screws until the black pins no longer move.

