

## VT58 PARTS LIST

序号	名称	NAME	序号	名称	NAME
1	门把手	Door handle	30	线夹	Wire clip
2	玻璃	Glass	31	右侧板加强件	Fortified part of right side board
3	锁盖板	Lock cover board	32	风机支撑	Support of fan motor
4	锁	Lock	33	风叶	Fan blade
5	左搁架支撑	Support of right shelve	34	风机	Fan motor
6	门框	Door frame	35	过线圈	Power cord protector
7	门封条	Door gasket	36	后盖板	Back cover board
8	门轴衬	Doorpost jacket	37	右侧板	Right side board
9	档条	Pullback	38	左侧板加强件	Fortified part of left side board
10	搁架	Shelf	39	上门轴	upper door hinges
11	右搁架支撑	Support of shelve	40	积水槽	Slot of seeper
12	支撑盖	Supportor plastic cover	41	顶盖板	Topmost board
13	滚轮	Wheel	42	左侧板	Left side board
14	滚轮支撑	Support of idler wheel	43	蒸发板	Evaporator
15	控制板	Control board	44	过滤器	Filter
16	通风栅	Grill	45	积水管	Pipe of seeper
17	控制盒	Control box	46	灯	Lamp
18	锁舌档板	Lock pullback	47	灯盒	Lamp box
19	控制盒盖板	Cover of control box	48	灯座	Lampholder
20	下门轴盖	Plastic cover of down door hinge	49	卡钩	Tache
21	下门轴	Down door hinges	50	灯盖板	Lamp cover board
22	冷凝器	Condenser	51	内胆	Cabinet liner
23	风道隔板	Separater	52	显示板	Temperature display board
24	积水盘	Drip pan	53	数码温控罩	Temperature control board cover
25	压缩机	Compressor	54	数码温控PVC	Numeral Temperature control PVC
26	底板	Motherboard	55	闷头	Stopple
27	可调底脚	Adjusting leg	56	上门轴孔塞	Plug of upper door hinges
28	减震垫圈	Gasket			
29	电源线	Power supply cord			

# VT58 Explode Drawing

