



# Alcohol Breath Tester

## IMPORTANT SAFETY INSTRUCTIONS

- Read ALL instructions before using this device.
- Do not use this device for other than its intended purpose.
- Exercise caution and use reasonable supervision when device is used near children. Never allow children to operate or play with unit.
- Intended for household use only.
- Locate the unit away from direct flames and other sources of heat (stove, heater, radiator, etc).
- Do not immerse in water or other liquids. Avoid locating the unit in moist areas.

## TESTER SPECIFICATIONS

<b>Power</b>	Lithium-Polymer Battery. 3.6V 180mAH
<b>Warm-Up Time</b>	≤ 10 seconds
<b>Measurement Time</b>	≤ 5 seconds
<b>Charging Time</b>	Approx. 2.5 hours
<b>Charging Current</b>	Approx. 180mA
<b>Ambient Temp (while operating)</b>	32 ° F ~ 120° F
<b>Storage Temperature</b>	0° F ~ 112° F

## OPERATING INSTRUCTIONS

To use the keychain breath tester, press the button to turn on and allow approximately 10 seconds for unit to start up. When the indicator light is green, the unit is ready to begin testing. Blow into the opening in the unit for several seconds. An indicator light will come on letting you know your approximate BAC range.

### Colored lights indicate blood alcohol content:

- **Green Light (Safe):** <0.05% BAC (or 0.25mg/L BRAC)
- **Orange Light (Alarm):** between 0.05% and 0.08% BAC (or 0.25 mg/L BRAC and 0.40mg/L BRAC)
- **Red Light (Danger):** >0.08% BAC (or 0.40mg/L BRAC)

**Recharge unit:** When the indicator lights become too dim, the unit needs to be recharged. Insert one end of standard USB cable into the unit and plug the other end into computer or wall outlet for approximately 2.5 hours. When unit is recharging, charge indicator is shining orange. Indicator light will be green when the recharge process is complete. USB cable not included.

**TIP:** For the most accurate reading, it is best to wait 20 minutes after consuming your last alcoholic drink before using the tester. Any alcohol that is left in your mouth is more highly concentrated compared to the alcohol in the breath that you would otherwise exhale and as such may cause inaccurate blood alcohol readings.

**Note:** This product displays approximate BAC based off of BRAC measurements and will have a variance and is intended for entertainment purposes only.

## TERMS OF SALE & WARRANTY

Epicureanist LLC ("Seller") and the person or entity that acquires these goods from Seller ("Purchaser") hereby fully agree to the following terms and conditions of the sale: Shipping fees are the responsibility of the Purchaser whether freight prepaid or freight collect. Seller assumes no responsibility for the goods sold to the Purchaser once the goods have left the Seller's premises, including, but not limited to, late delivery by the moving carrier, or for events caused by any difficulty carrier incurs in attempting to fit the goods into the Purchaser's place of business or residence due to the size of the goods or otherwise. Purchaser assumes all responsibility for delivery, payment of freight, access, measurement, installation, hook-up, wiring, moving and storage of the goods. The transportation of all goods is subject to the terms and conditions which the moving carrier imposes on Purchaser including, but not limited to, additional charges imposed per flight of stairs, and/or additional charges resulting from the carrier's inability to safely and/or adequately use the building elevator to lift the goods to an upper floor. Any claim for damages incurred during shipment by the carrier of the goods are insured and handled directly with the carrier. Any damages due to manufacture defects will be handled directly with Epicureanist LLC, subject to the limited warranty.

All sales are final, and unless authorized in writing by the Seller, Purchaser may not return the goods, under any circumstance. If Purchaser refuses to accept the goods, under any circumstance, the Purchaser is liable for the return and cost of freight both ways, and if Seller does take back the goods, there will be a restocking charge that is 35% of the purchase price of the goods. Racking is nonrefundable. Purchaser must notify Seller of non-conforming goods within four days of delivery, after which time all goods are deemed accepted. If an order has been placed and production has started, cancellation of your order will be a 15% charge.

If Purchaser tenders payment with a check that has insufficient funds (NSF), or stops payment on a check or credit card for any reason, Purchaser agrees to pay for all costs associated with the Seller's connection or litigation of such a claim, including without limitation extra damages, court costs and attorneys' fees. Finance charges begin the date of invoice. Collection fees plus NSF fee of \$50 will be added to your invoice, which you agree to promptly pay. Title to the goods does not pass until payment is received in full by Seller and Seller retains a security interest in the goods until they are paid for in full.

Epicureanist does not warrant wine accessories. Purchaser understands and acknowledges that the goods sold here are wine storage products and accessories. Purchaser assumes all risk of using these units, including risk of spoilage, humidity variations, temperature variations, leaks, fire, water damage, mold, mildew, dryness and similar and any other perils that might occur.

Seller is not responsible for incidental or consequential damages, and there are no warranties, expressed or implied, which extend beyond the Limited Warranty described above. The implied warranties of merchantability and of fitness for a particular purpose are hereby expressly disclaimed. Some states do not allow the exclusion of incidental or consequential damages, or a waiver of the implied warranties of fitness and/or merchantability, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

In the event of any dispute between Seller and Purchaser arising out of or relating to these terms and conditions or to the goods sold generally, Purchaser must first file a written claim with Seller within ten days of the occurrence giving rise to the claim and wait an additional thirty days for a response before initiating any legal action. The sale and all terms are subject to California law. Any legal proceeding arising out of or relating to these terms and conditions or to the goods sold generally shall be brought solely and exclusively in the County of Los Angeles. In no event may Purchaser initiate any legal proceeding more than six months after the occurrence of the event giving rise to the dispute.

The above terms and conditions are the only ones governing this transaction and Seller makes no oral representations of any kind. These Terms and Conditions can only be modified in writing, signed by both Purchaser and Seller.

**IMPORTANT NOTICE:** The manufacturer has a policy of continuous improvement on its products and reserves the right to change materials and specifications without notice. This instrument is to be used for reference purposes only and its reading should not be treated as conclusive or as confirmation of the level of intoxication. The manufacturer, distributor and seller are not responsible for any consequences arising from reliance on such readings. Any liability of the manufacturer, distributor and seller (whether arising out of contract, tort or otherwise) will be limited to the retail price of the instrument.

**WARNING: Please do not place the unit within reach of children. For adult use only.**

Contact [info@epicureanist.com](mailto:info@epicureanist.com) with any questions or visit [www.epicureanist.com](http://www.epicureanist.com)

Epicureanist is a trademark of Epicureanist LLC. All products, features, and services are subject to change without notice. We cannot guarantee the accuracy of the contents of this document. We disclaim liability for errors, omissions, or future changes.

© 2010 Epicureanist LLC. All rights reserved.