



# Electric Bottle Opener



**EP-CORKEL2**

**OWNER'S MANUAL**

# EPICUREANIST ELECTRIC BOTTLE OPENER

Epicureanist Electric Bottle Opener couples style and functionality, effortlessly opening corked bottles within moments. It is rechargeable and designed to fit most standard 750ml wine bottles.

**PLEASE READ ALL INSTRUCTIONS BEFORE USE**

**-SAVE INSTRUCTIONS-**

## IMPORTANT SAFETY INSTRUCTIONS

- Do not use this device for other than its intended purpose.
- Exercise caution and use reasonable supervision when device is used near children. Never allow children to operate or play with unit.
- Intended for indoor household use only.
- Locate the unit on a steady surface away from direct flames and other sources of heat (stove, heater, radiator, etc).
- Do not immerse in water or other liquids. Avoid locating the unit in moist areas.
- For safety and best results, do not operate unit in an ambient temperature outside the range of 32°-95°F.
- Do not use the unit as a handle to lift or move the bottle. This may cause the bottle to fall from the appliance.
- Do not operate if unit, cord or plug is damaged. Return to the manufacturer for examination or repair.
- When charging, always plug DC cord into unit first, then plug AC cord into electrical outlet. To disconnect, remove the AC cord first then the DC power cord. Always unplug the unit before taking off parts or attachments.


**WARNING:** Electric Bottle Opener corkscrew is sharp. Handle with care. Hold the opener by its outer housing only. Keep hands and objects away from mechanism during operation to prevent injury or damage.

# CHARGING YOUR BOTTLE OPENER

Unit requires 12 hour charge before first use. To charge:

- Plug DC connector into unit, then plug AC end into electrical outlet.
- Place Bottle Opener into charging base properly to ensure charge.
- Charging base will start working automatically and the indicator light will show red while charging.
- When the charging process is complete, indicator light will show green when the Bottle Opener is ready.

## BOTTLE OPENER DIAGRAM



- |    |                     |    |                         |
|----|---------------------|----|-------------------------|
| 1. | Bottle Opener       | 5. | Charging Base           |
| 2. | Upper Button        | 6. | Foil Cutter (Removable) |
| 3. | Lower Button        | 7. | DC In                   |
| 4. | LED Indicator Light | 8. | AC/DC Adaptor           |

## OPENING A SEALED BOTTLE

- Remove any foil from the bottle by using the magnetized removable foil cutter. While holding the lower half of the bottle firmly, affix the foil cutter to the top of the bottle and twist to remove foil.
- Ensure that the bottle remains upright, then place the Bottle Opener firmly against the top of the bottle. Holding the Bottle Opener at an angle to the bottle may result in improper removal of cork.
- Press the lower button to engage the Opener. The corkscrew spiral will now turn counter-clockwise and enter the cork, gradually removing it from the bottle. When the cork has been fully removed, the Electric Bottle Opener will stop.
- Lift the Bottle Opener away from the bottle. Press the upper button and the corkscrew spiral will turn clockwise and release the cork.
- During periods of inactivity, return the Opener to its charging base.

## CARE AND MAINTENANCE

- Always store your Electric Bottle Opener in a cool, dry place.
- Always disconnect before cleaning. To clean, wipe housing with a soft and dry cloth. Do not use liquid or abrasive cleaning agents.

## TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE
LED indicator light does not work	<ul style="list-style-type: none"><li>• Check if the DC cord is in good condition</li><li>• Check if the electrical outlet is in good condition</li><li>• Check if the plug is connected properly</li><li>• Check if the charging base has been damaged</li></ul>
Bottle Opener does not work	<ul style="list-style-type: none"><li>• Check if Bottle Opener needs to be recharged</li><li>• Check if Bottle Opener has been damaged</li></ul>

# IMPORTANT DISPOSAL INSTRUCTIONS



As a responsible company, we care about the environment.

As such, we urge you to follow the correct disposal procedures for your product, batteries, and packaging materials. This will help conserve natural resources and ensure that it is recycled in a manner that protects health and the environment.

You must dispose of this product and its packaging according to local laws and regulations. Because this product contains electronic components and sometimes batteries, the product and its accessories must be disposed of separately from household waste when the product reaches its end of life cycle.

The product and batteries should be taken to a proper recycling/disposal facility.

# TERMS OF SALE & WARRANTY

Epicureanist ("Seller") and the person or entity that acquires these goods from Seller ("Purchaser") hereby fully agree to the following terms and conditions of the sale: Shipping fees are the responsibility of the Purchaser whether freight prepaid or freight collect. Seller assumes no responsibility for the goods sold to the Purchaser once the goods have left the Seller's premises, including, but not limited to, late delivery by the moving carrier, or for events caused by any difficulty carrier incurs in attempting to fit the goods into the Purchaser's place of business or residence due to the size of the goods or otherwise. Purchaser assumes all responsibility for delivery, payment of freight, access, measurement, installation, hook-up, wiring, moving and storage of the goods.

The transportation of all goods is subject to the terms and conditions which the moving carrier imposes on Purchaser including, but not limited to, additional charges imposed per flight of stairs, and/or additional charges resulting from the carrier's inability to safely and/or adequately use the building elevator to lift the goods to an upper floor. Any claim for damages incurred during shipment by the carrier of the goods are insured and handled directly with the carrier. Any damages due to manufacture defects will be handled directly with Epicureanist, subject to the limited warranty.

All sales are final, and unless authorized in writing by the Seller, Purchaser may not return the goods, under any circumstance. If Purchaser refuses to accept the goods, under any circumstance, the Purchaser is liable for the return and cost of freight both ways, and if Seller does take back the goods, there will be a restocking charge that is 35% of the purchase price of the goods. Racking is nonrefundable. Purchaser must notify Seller of non-conforming goods within four days of delivery, after which time all goods are deemed accepted. If an order has been placed and production has started, cancellation of your order will be a 15% charge.

If Purchaser tenders payment with a check that has insufficient funds (NSF), or stops payment on a check or credit card for any reason, Purchaser agrees to pay for all costs associated with the Seller's connection or litigation of such a claim, including without limitation extra damages, court costs and attorneys' fees. Finance charges begin the date of invoice. Collection fees plus NSF fee of \$50 will be added to your invoice, which you agree to promptly pay. Title to the goods does not pass until payment is received in full by Seller and Seller retains a security interest in the goods until they are paid for in full.

Epicureanist does not warrant wine accessories. Purchaser understands and acknowledges that the goods sold here are wine storage products and accessories. Purchaser assumes all risk of using these units, including risk of spoilage, humidity variations, temperature variations, leaks, fire, water damage, mold, mildew, dryness and similar and any other perils that might occur. Seller is not responsible for incidental or consequential damages, and there are no warranties, expressed or implied, which extend beyond the Limited Warranty described above. The implied warranties of merchantability and of fitness for a particular purpose are hereby expressly disclaimed. Some states do not allow the exclusion of incidental or consequential damages, or a waiver of the implied warranties of fitness and/or merchantability, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

In the event of any dispute between Seller and Purchaser arising out of or relating to these terms and conditions or to the goods sold generally, Purchaser must first file a written claim with Seller within ten days of the occurrence giving rise to the claim and wait an additional thirty days for a response before initiating any legal action. The sale and all terms are subject to California law. Any legal proceeding arising out of or relating to these terms and conditions or to the goods sold generally shall be brought solely and exclusively in the County of Los Angeles. In no event may Purchaser initiate any legal proceeding more than six months after the occurrence of the event giving rise to the dispute.

The above terms and conditions are the only ones governing this transaction and Seller makes no oral representations of any kind. These Terms and Conditions can only be modified in writing, signed by both Purchaser and Seller.



Contact [info@epicureanist.com](mailto:info@epicureanist.com) with any questions or visit [www.epicureanist.com](http://www.epicureanist.com)



Costa Mesa, CA 92627  
[www.epicureanist.com](http://www.epicureanist.com)

**SERVICE & IMPORTANT NOTICE**

The manufacturer has a policy of continuous improvement on its products and reserves the right to change materials and specifications without notice.

**WARNING:**

**Please do not place the unit within reach of children.  
For adult use only.**

Epicureanist is a trademark of Epicureanist LLC. All products, features, and services are subject to change without notice. We cannot guarantee the accuracy of the contents of this document. We disclaim liability for errors, omissions, or future changes.

©2010 Epicureanist LLC. All rights reserved.